

A man with a beard and safety glasses is using a Ryobi trimmer in a garden. He is wearing a grey t-shirt, blue jeans, and work boots. The trimmer is yellow and black. The background shows green foliage and a dark grey building.

**RYOBI**

GUIDE ACCESSOIRES  
**ÉQUIPEMENTS  
DE PROTECTION**

**3 ANS**  
DE GARANTIE\*

ryobitools.fr

\* Garantie 2 ans + 1 an d'extension offert, voir conditions sur le site Ryobi® : ryobitools.fr



**RAC811S / RAC811M / RAC811L / RAC811XL**

5132003273 / 5132002992 / 5132002991 / 5132003439

Gants de jardinage renforcés et tactiles – taille S / M / L / XL



**RAC258S / RAC258M / RAC258L / RAC258XL**

5132005709 / 5132005710 / 5132005711 / 5132005712

Gants anti-coupures 24 m/s (catégorie 2) pour tronçonneuses - taille S / M / L / XL





**RAC368**

5132005708

Sac pop-up pour déchets de végétaux - 150 L toile d'Oxford - pliable et autoportant



**RAC256**

5132005708

Sac de transport pour tronçonneuses électriques et sur batterie

